

ALARM
MONITORING
DATA LOGGING

AS300 SYSTEM APN SETTINGS



Section 1 ► NETWORK SETTINGS (APN Settings)

For data to be sent to the server the network settings must be set up in the AS300SA or AS300RX. Each network has different settings, the AS300SA or AS300RX by default is setup for a O2 PAYG SIM.

If you have purchased your PAYG SIM with the AS300SA or AS300RX the relevant network settings will have been set for you.

Settings For O2 PAYG Sim cards

For data to be sent to the server the network settings must be set up in the unit. Each network has different settings, the unit by default is setup for a O2 sim.

APN Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPAPNspacepayandgo.o2.co.uk**

***** IPAPN payandgo.o2.co.uk**

User Name Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPUSRspacepayandgo**

***** IPUSR payandgo**

Password Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPPWDspacepassword**

***** IPPWD password**

Settings For Vodafone PAYG Sim cards

For data to be sent to the server the network settings must be set up in the unit.

APN Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPAPNspacevodafone.co.uk**

***** IPAPN vodafone.co.uk**

User Name Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPUSRspacewap**

***** IPUSR wap**

Password Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPPWDspacewap**

***** IPPWD wap**

Settings For Orange PAYG Sim cards

For data to be sent to the server the network settings must be set up in the unit. Each network has different settings, the unit by default is setup for a O2 sim.

APN Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPAPNspaceorangeinternet.co.uk**

***** IPAPN orangeinternet.co.uk**

User Name Setting

Send a text a message to the AS300SA Unit with the following text :-

*****spaceIPUSRspaceorange**

***** IPAPN orange**

Password Setting

Send a text a message to the AS300SA Unit with the following text :-
text a message to the AS300SA Unit with the following text :-

*****spaceIPPWDspace''''**

***** IPPWD ''''**

Settings For T-Mobile PAYG Sim cards.

For data to be sent to the server the network settings must be set up in the unit

APN Setting

Send a text a message to the AS300SA Unit with the following text :-

*****#spaceIPAPNspacegeneral.t-mobile.uk**

*****# IPAPN general.t-mobile.uk**

User Name Setting

Send a text a message to the AS300SA Unit with the following text :-

*****#spaceIPUSRspaceuser**

*****# IPUSR**

Password Setting

Send a text a message to the AS300SA Unit with the following text :-

*****#spaceIPPWDspacewap**

*****# IPPW wap**

Checking APN Settings in the AS300SA

Send a text a message to the AS300SA Unit with the following text :-

*****#spaceGPRS?**

*****# IGPRS?**

A message will be sent back to the mobile with APN settings.